



USB 2.0 Video Capture Device Quick Installation Guide

Introducing the *USB 2.0 Video Capture*

The *USB 2.0 Video Capture Device* easily captures video from VHS or any external source and record to DVD.

Features and Benefits

- USB 2.0 Plug and Play
- Supports External A/V/S-video inputs
- VCD/DVD/SVCD authoring
- Compress TV programs to MPEG-1/2
- Supports NTSC/PAL format

System Requirements

- PC computer with an available USB 2.0 port and sound card
- Windows® 7 (32-/64-bit) / Vista (32-/64-bit) / XP (32-/64-bit)

Serial Number Sticker

For future product return or exchange, this serial number is required. Please keep it for your reference.



Package Contents

- *USB 2.0 Video Capture Device*
- USB extension cable
- Software CD
- Quick Installation Guide

Layout



Figure 1: Layout

Note: When using the S-Video, you must connect Audio L/R to hear the sound.

Hardware Installation

Windows 7 (32-bit)

1. Boot up Windows, at the Windows desktop insert the driver CD.
At the AutoPlay box: Click **Open folder to view files**. Double click **32bit** folder, double click **Install**.
If the AutoPlay box doesn't start: Click **Start** button, in **Start Search**, type **D:\32bit\install.exe**, then press **Enter**. (Change **D:** to match your CD/DVD-ROM drive letter)
3. At **User Account Control**, click **Yes**.
4. At **Please plug in device** box, insert the *USB 2.0 Video Capture Device* into a USB port, then click **OK**.
5. Click **Install this driver software anyway**.
6. At **Setup Completed**, click **Close** then restart Windows to complete the installation.

Windows 7 (64-bit)

1. Boot up Windows, at the Windows desktop insert the driver CD.
At the AutoPlay box: Click **Open folder to view files**. Double click the **64bit** folder, double click **Install**.
If the AutoPlay box doesn't start: Click the **Start** button, in **Start Search**, type in **D:\64bit\install.exe**, then press **Enter**. (Change **D:** to match your CD/DVD-ROM drive letter)

3. At **User Account Control**, click **Yes**.
4. At **Please plug in device** box, insert the *USB 2.0 Video Capture Device* into a USB port, then click **OK**.
5. Click **Install this driver software anyway**.
6. At **Setup Completed**, click **Close** then restart Windows to complete the installation.

Windows Vista™ (32-bit)

Please disconnect your computer from your network connection before installing the *USB 2.0 Video Capture Device*.

1. Boot up Vista. Insert the *USB 2.0 Video Capture Device* into a USB port.
2. At the **Found New Hardware** window, click **Locate and install driver software (recommended)**, then click **Continue**.
3. Click **Don't Search Online**. Skip this step and go directly to next step if not prompted.
4. Click **I don't have the disc. Show me other options**. Click **Browse my computer for driver software (Advanced)**. Insert the driver CD.
5. Type in **D:\32bit\Driver**, then click **Next**. (Change **D:** to match your CD/DVD-ROM drive letter)
6. Click **Install this driver software anyway**.
7. Click **Close** to complete the installation.

Windows Vista (64-bit)

Please disconnect your computer from your network connection before installing the *USB 2.0 Video Capture Device*.

1. Boot up Vista. Insert the *USB 2.0 Video Capture Device* into a USB port.
2. At the **Found New Hardware**, click **Locate and install driver software (recommended)**, then click **Continue**.
3. Click **Don't Search Online**. Skip this step and go directly to next step if not prompted.
4. Click **I don't have the disc. Show me other options**. Click **Browse my computer for driver software (Advanced)**. Insert the driver CD.
5. Type in **D:\64bit\Driver**, then click **Next**. (Change **D:** to match your CD/DVD-ROM drive letter)
6. Click **Install this driver software anyway**.
7. Click **Close** to complete the installation.

Windows XP (32-bit)

1. Boot up XP. Insert the *USB 2.0 Video Capture Device* into a USB port.
2. At the **Found New Hardware Wizard**, click **No, not this time**, then click **Next**.
3. Check **Install from a list or specific location**, then click **Next**. Insert the driver CD.

4. Check **Include this location in the search**, type in **D:\32bit\driver**, then click **Next**. (Change **D:** to match your CD-ROM drive letter)
5. Click **Continue Anyway**.
6. Click **Finish** to complete the installation.

Windows XP (64-bit)

1. Boot up XP. Insert into USB port.
2. At the **Found New Hardware**, click **No, not this time**, then click **Next**.
3. Insert the driver CD, select **Install the software automatically**, then click **Next**.
4. Click **Continue Anyway**.
5. Click **Finish** to complete the installation.

To Verify Windows Installation

1. Right click **Computer** or **My Computer**, then click **Manage**.
For Windows 7 / XP: Click **Device Manager**.
For Windows Vista: Click **Continue**, then click **Device Manager**.
2. Double click **Sound, video and game controllers**, a **Trident Analog Video** should be displayed.

Honestech VHS to DVD 3.0 SE Utility

You must set the resolution to 1024x768 or higher to work properly.

Software Installation

1. Insert the driver CD.
For Window 7: Click **Start**, in the **Start Search** box, type in **D:\App\Setup.exe**, press **Enter**, click **Yes**. (Change **D:** to match your CD/DVD-ROM drive letter)
For Window Vista: Click **Start**, in the **Start Search** box, type in **D:\App\Setup.exe**, press **Enter**, then click **Allow**. (Change **D:** to match your CD/DVD-ROM drive letter)
For Windows XP: Click **Start**, **Run**, type in **D:\App\Setup.exe**, then click **OK**. (Change **D:** to match your CD/DVD-ROM drive letter)
2. Select your **language**, then click **Next**.
3. At the **Welcome** screen, click **Next**.
4. Check **I accept the terms of the license agreement**, then click **Next**.
5. At the **Choose the Destination Location**, click **Next**.
6. At **Select Program Folder**, click **Next**.
7. At **Ready to Install the Program**, click **Install**.
8. At **Windows Media Format 9 Series Runtime Setup**, click **Yes**, click **Yes** again, then click **OK**. Skip this step and go directly to step 9 if not prompted.

9. Click **Finish** to complete the installation.

Note: For Windows Vista, disable sleep and hibernation mode when recording or capturing.

Entering the Serial Number

Click **Start/All Programs/Honestech VHS to DVD 3.0 SE/Honestech VHS to DVD 3.0 SE**, enter the serial number, found with the driver CD, when running the program for the first time.

Users Manual

For instructions on how to use the **Honestech VHS to DVD 3.0 SE**, please click **Start/All Programs/Honestech VHS to DVD 3.0 SE/Help for Honestech VHS to DVD 3.0 SE** or click the question mark on the top right side of your screen while the **Honestech VHS to DVD 3.0 SE** is running.

Blank Page

Blank Page

Technical Support and Warranty

QUESTIONS? SIIG's **Online Support** has answers! Simply visit our web site at www.siig.com and click **Support**. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and a technical support analysts will promptly respond.

SIIG offers a 2-year manufacturer warranty with this product. Please see our web site for more warranty details. If you encounter any problems with this product, please follow the procedures below.

If it is within the store's return policy period, please return the product to the store where you purchased from. If your purchase has passed the store's return policy period, please follow these steps to have the product repaired or replaced.

Step 1: Submit your RMA request.

Go to www.siig.com, click **Support**, then **RMA** to submit a request to [SIIG RMA](#). If the product is determined to be defective, an RMA number will be issued.

Step 2: After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG will refuse to accept any shipping package, and will not be responsible for a product returned without an RMA number posted on the outside of the shipping carton.
- You are responsible for the cost of shipping. Ship the product to the following address:

SIIG, Inc.
6078 Stewart Avenue
Fremont, CA 94538-3152, USA
RMA #: _____

- SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

About SIIG, Inc.

Founded in 1985, SIIG, Inc. is a leading computer upgrade manufacturer of I/O connectivity products, including PCI & ISA serial and parallel ports, USB, Serial ATA & UltraATA controllers, FireWire (1394a/b), networking, sound cards, and other accessories. SIIG is the premier one-stop source of upgrades.

SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High-quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, through major distributors, system integrators, and VARs in the Americas and the UK, and through e-commerce sites.

PRODUCT NAME

USB 2.0 Video Capture Device

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS B
OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.

6078 Stewart Avenue

Fremont, CA 94538-3152, USA

Phone: 510-657-8688

USB 2.0 Video Capture Device is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. Microsoft, Windows and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other names used in this publication are for identification only and may be trademarks of their respective companies.

October, 2009

Copyright © 2009 by SIIG, Inc. All rights reserved.