

Portable Battery Power Bank Plus USB Light Combo Installation Guide

Introduction

Key Features and Benefits

- Charges most Smartphones, Tablets, eBook Readers, Digital Cameras, MP3/MP4 Players and other USB powered portable devices
- Extra bright detachable USB powered LED light, easily turns the power bank unit into a portable flashlight
- High quality Lithium-ion rechargeable battery. Simply recharge it through any standard USB port or USB wall charger (with the included Micro USB charging cable)
- 1A power output supports fast charging

LOT Number Sticker

For future product return or exchange, this LOT number is required. Please keep it for your reference.

04-0935A 1

Package Contents

- Portable Battery Power Bank Plus USB Light Combo
- USB charging cable
- Carrying pouch
- Installation guide

Layout




Figure 2: USB Charging Cable

- Power-in (Micro USB): Connects to a computer's USB port or USB wall charger (not included) to charge the *Power Bank*
- Power-out (USB Type A): Connect smartphones or other USB powered portable devices here
- USB Connector and LED light (Figure 1a):
 Connects to the Power Banks's Power-out port to use the USB light
- On/Off button: Quickly press twice to power On/Off the *Power Bank*, USB light and charge portable devices
- **LED indicator**: Indicates the *Power Bank* status
 - LED off: Power Bank is off
 - Last bar is blinking: The portable device is being charged
 - Running: Power Bank is recharging
 - Battery charge level indicator: See Table 1

one LED on	two LEDs on	three LEDs on	four LEDs on
<25%	25%-75%	50%-75%	75%-100%

Table 1

Instructions for Use

Charging the Power Bank

Note: Fully charge the *Power Bank* before use. Please use the included **USB charging cable** to charge the *Power Bank*.

 Plug the Micro USB tip of included USB charging cable into the *Power Bank's* Power-in port. Then plug the other end of the included USB charging cable into either a USB port of your computer or your USB wall charger. See Figure 3.




Figure 3

2. The *Power Bank*'s LED indicator will light up to indicate the charging process has begun.

3. When the *Power Bank* is fully charged, all the four LED indicators will be lit and go off automatically. It takes approximately 5-6 hours to fully charge the *Power Bank*. The actual charging time will vary depending on the *Power Bank*'s charge status and/or the external power source's power output.

Charging Portable Devices

Note: It is recommended to use the portable device's original equipment USB charging cable to charge it.

1. Plug the USB Type A tip of your portable device's USB charging cable into the *Power Bank*'s **Powerout** port, then connect the other end of the charging cable into the portable device. See Figure 4.




Figure 4

2. Quickly press the *Power Bank*'s **On/Off button** twice to start charging your portable device.

Using the USB Light

- 1. Insert the USB Light's **USB connector** into the *Power Bank's* **Power-out** port.
- 2. Quickly press the *Power Bank's* **On/Off button** twice to turn on the USB light. Press the button twice again to turn off the USB light.



Figure 5

Trouble Shooting Tips

- Due to the Power Bank's limited battery capacity, it is not recommended to use with Tablet devices.
- The Power Bank's protection circuit may be triggered due to improper cable connection or device connection. To reset the circuit, simply repeat the battery charging process (see page 4, steps 1 & 2) for a few minutes and the unit will return to normal operating mode.

Technical Support and Warranty

QUESTIONS? SIIG's Online Support has answers! Simply visit our web site at www.siig.com and click Support. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and a technical support analyst will promptly respond.

SIIG offers a 2-year manufacturer warranty with this product. This warranty covers the original purchaser and guarantees the product to be free of any defects in materials or workmanship for two (2) years from the date of purchase of the product.

SIIG will, at our discretion, repair or replace (with an identical product or product having similar features and functionality) the product if defective in materials or workmanship. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Please see our web site for more warranty details.

If you encounter any problems with this product, please follow the procedures below. A) If it is within the store's return policy period, please return the product to the store where you purchased from.

B) If your purchase has passed the store's return policy period, please follow the steps below to have the product repaired or replaced.

Step 1: Submit your RMA request.

Go to www.siig.com, click Support, then REQUEST A PRODUCT REPLACEMENT to submit a request to <u>SIIG RMA</u> or fax a request to 510-657-5962. Your RMA request will be processed, if the product is determined to be defective, an RMA number will be issued.

Step 2: After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG will
 refuse to accept any shipping package, and will not be responsible for a product
 returned without an RMA number posted on the outside of the shipping
 carton.
- You are responsible for the cost of shipping to SIIG. Ship the product to the following address:

SIIG, Inc. 6078 Stewart Avenue Fremont, CA 94538-3152, USA RMA #:

 SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

About SIIG, Inc.

Founded in 1985, SIIG, Inc. is a leading manufacturer of IT connectivity solutions (including Serial ATA and Ultra ATA Controllers, FireWire, USB, and legacy I/O adapters) that bridge the connection between Desktop/Notebook systems and external peripherals. SIIG continues to grow by adding A/V and Digital Signage connectivity solutions to our extensive portfolio. SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, through major distributors, system integrators, and VARs in the Americas and the UK, and through e-commerce sites.

PRODUCT NAME

Portable Battery Power Bank Plus USB Light Combo

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS B OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.

6078 Stewart Avenue

Fremont, CA 94538-3152, USA

Phone: 510-657-8688

Portable Battery Power Bank Plus USB Light Combo is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. All other names used in this publication are for identification only and may be trademarks of their respective owners.

December, 2013 Copyright © 2013 by SIIG, Inc. All rights reserved.