



Sync/Charging Hub + Reader for Galaxy Tablets

Quick Installation Guide

Introduction

The *Sync/Charging Hub+Reader for Galaxy Tablets* allows you to sync, charge, import images, videos, music and more for a variety of Galaxy Tablets.

Key Features and Benefits

- Switchable sync/charging cable - choose data synchronization or charging modes
- Supports MicroSD/MicroSDHC/T-Flash / microMMC memory cards for PC & Mac
- Two USB 2.0 ports for connecting USB devices (PC & Mac only)
- Compatible with Galaxy Tab 7.0/7.0 Plus/ 7.7/8.9/10.1, Galaxy Tab 2 7.0/10.1

Package Contents

- Sync/Charging Hub+Reader for Galaxy Tablets
- Quick installation guide

Layout




Figure 1: Layout

- 1 Data/Charging Switch:**
Data mode: USB 2.0 hub and cardreader for your PC or Mac computer or sync with your Galaxy Tablet
Charge mode: Charges your Galaxy Tablet
- 2 USB 2.0 port:** Connects USB devices to your desktop or notebook computer
- 3 microSD slot:** Insert your memory cards to transfer files to your computer
- 4 USB 2.0 port:** Connects USB devices to your desktop or notebook computer
- 5 USB 2.0 Type A connector:** Connects to computer or Galaxy Tablet charger
- 6 30-pin Connector:** Connects to your Galaxy Tablet

Synchronizing your Data

1. Move the switch to **Data mode**.
2. Connect your Galaxy Tablet to the cable's **30-pin Connector**.
3. Connect the other end of the cable to your computer's USB port.
4. Sync to the Galaxy Tablet just as you would with the original Samsung cable.

Charging Your Galaxy Tablet

Connect to Computer

Note: Charging your Galaxy Tablet may interfere with other connected USB devices, in this case, we recommend charging with an AC adapter or car charger.

1. Move the switch to **Charge mode**.
2. Connect your Galaxy Tablet to the cable's **30-pin Connector**.
3. Connect the other end of the cable to your computer's USB port. The Galaxy Tablet will charge automatically.

AC Adapter Charging

1. Connect your Galaxy Tablet to the cable's **30-pin Connector**.
2. Move the switch to **Charge mode**.
3. Connect the other end of the cable to your AC adapter. Plug the AC adapter into a reliable power outlet. The Galaxy Tablet will charge automatically.




Figure 4: AC Adapter Charging

Car Charger

It is recommended to use a car charger with minimum 1A power output.

1. Connect your Galaxy Tablet to the cable's **30-pin Connector**.
2. Move the switch to **Charge mode**.
3. Connect the other end of the cable to your car charger. Plug the car charger into a reliable power outlet. The Galaxy Tablet will charge automatically.




Figure 5: Car Charger

USB 2.0 Hub & microSD Cardreader

The USB 2.0 Hub & microSD Cardreader are supported only on Windows® 7/Vista/XP and Mac OS® X 10.5 or later desktop or notebook computers.

1. Move the switch to **Data mode**.
2. Connect the cable's **USB 2.0 Type A connector** to your computer's USB port. The drivers will install automatically.
3. The USB 2.0 Hub and microSD Cardreader are ready for use.




Figure 6: Connect USB Devices




Figure 7: Insert Memory Card with Gold Pins Facing Up

Technical Support and Warranty

SIIG offers a 1-year manufacturer warranty with this product. This warranty covers the original purchaser and guarantees the product to be free of any defects in materials or workmanship for one (1) year from the date of purchase of the product. Please see our web site for more warranty details.

If you encounter any problems with this product, please follow the procedures below. If your purchase has passed the store's return policy period, please follow the steps below to have the product repaired or replaced.

Step 1: Submit your RMA request.

Go to www.siig.com, click **Support**, then **REQUEST A PRODUCT REPLACEMENT** to submit a request to [SIIG RMA](#) or fax a request to 510-657-5962. Your RMA request will be processed, if the product is determined to be defective, an RMA number will be issued.

Step 2: After obtaining an RMA number, ship the product. Properly pack the product for shipping. All accessories that came with the original package must be included. Clearly write your RMA number on the top of the returned package. SIIG will refuse to accept any shipping package, and will not be responsible for a product returned without an RMA number posted on the outside of the shipping carton. You are responsible for the cost of shipping to SIIG. Ship the product to the following address:

SIIG, Inc. 6078 Stewart Avenue Fremont, CA 94538-3152, USA

RMA #: _____

SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

PRODUCT NAME

Sync/Charging Hub+Reader for Galaxy Tablets

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS B

OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.

6078 Stewart Avenue

Fremont, CA 94538-3152, USA

Phone: 510-657-8688

Sync/Charging Hub+Reader for Galaxy Tablets is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. All other names used in this publication are for identification only and may be trademarks of their respective owners.

May, 2012

Copyright © 2012 by SIIG, Inc. All rights reserved.

