

## **Addendum**

## **Pairing Instructions**

If your system is not responding to the wireless keyboard, please follow the instructions below.

- 1. Unplug the Wireless Nano Dongle.
- 2. Press the wireless keyboard's pairing button located on the back of the keyboard. The wireless keyboard will stay in pairing mode for 9-10 seconds and the battery indicator light will be lit.
- 3. Re-plug the Wireless Nano Dongle into the same USB port.
- 4. The wireless keyboard's battery indicator light will go off when the pairing process is complete.
- 5. If the system is still not responding to the wireless keyboard, try steps 1-4 again. It may take several tries before successful.

**Note**: Please keep these instructions for future reference.

1