



# Dual View Wireless Media Presentation

## Quick Start Guide



04-1271A

P/N: CE-H25Y11-S1  
P/N: CE-H26611-S1  
P/N: CE-H26711-S1

## Features

- Support dual viewer on one display.
- Support VESA PC resolution input, auto-detecting.
- Can transmit PC's mirror/extended desktop or Macbook's mirror desktop.
- Can transmit smart devices' mirror, photos, videos, music etc.
- Support USB plug-in auto pairing for Wireless Media Presentation
- Support "Airplay" for apple device.

## Package contents (CE-H25Y11-S1)

- Dual View Wireless Media Presentation (WMS)
- USB A/C Dongle
- Power adapter DC 12V/1.5A
- Antenna x2
- Quick Start Guide

## Package contents (CE-H26611-S1)


- Dual View Wireless Media Presentation (WMS)
- Wireless Media Presentation Transmitter-HDMI Dongle x2
- USB A/C Dongle
- Power adapter DC 12V/1.5A
- Antenna x2
- Quick Start Guide

## Package contents (CE-H26711-S1)

- Wireless Media Presentation Transmitter-HDMI Dongle
- Quick Start Guide


# Layout

Front



1. **Front USB connector:** USB port, for dongle pairing, mouse control, USB touch screen etc.
2. **Front Type-C connector:** Type-C port, for dongle pairing.
3. **Back-lit LED indicator:** Initializing RED, power on flashing GREEN, "Ready to share" static GREEN, "Sharing" static cyan.
4. **Power button:** Power On/Off device

Rear



1. **Line output:** 3.5mm stereo audio output,
2. **USB3.0 connector:** USB port, for USB dongle pairing, mouse control, USB touch screen etc.
3. **Reset:** Reset button to restore to the factory default setting.
4. **HDMI output:** Connect a an HDMI display.
5. **RS-232:** reserved
6. **LAN Ethernet port 1:** 100Mbps.
7. **LAN Ethernet port 2:** 1Gbps. Support POE.
8. **DC Power socket:** Connect the included power adapter
9. **Antenna fixture points:** Screw up the included two antennas

# Connection Approach

## For PC/Laptop

### Method 1. Via Launcher “PC Software”

1. Connect your PC/Laptop’ Wi-Fi to the hotspot of WMS (ID and password showed on the Homepage).
2. Use USB flash drive to connect the USB port of WMS and click the download icon to get the “Launcher” (PC client software \*.exe)



The screenshot shows the WMS-3343 hotspot interface. At the top, it displays the ID: WMS-3343, PASS: 00003404(01:13), and IP addresses. Below this, there are icons for a Wi-Fi signal, a download icon (highlighted with a red box), an information icon, and a Wi-Fi connection icon. The interface is divided into two main sections: PC and Android/iOS. The PC section shows a laptop and a desktop monitor with three numbered steps: 1. Copy WirelessMedia.exe/app from USB stick or download by connecting SSID&PASS to enter WiFi IP browser page, to lap-top; 2. Plug the USB dongle into your PC/lap-top, click to run WirelessMedia; 3. Wait till LED indicator is static green, click button to show your screen. The Android/iOS section shows a QR code, an AirPlay icon, and a smartphone with two numbered steps: 1. Download APK/APP namely "WirelessMedia"; 2. Connect wireless network WMS-3343 and enter password; 3. Open the app and click Mirroring to show your mobile screen. The time 04:22 is displayed in the center.

**PC**

Step 1: Copy WirelessMedia.exe/app from USB stick or download by connecting SSID&PASS to enter WiFi IP browser page, to lap-top  
 Step 2: Plug the USB dongle into your PC/lap-top, click to run WirelessMedia  
 Step 3: Wait till LED indicator is static green, click button to show your screen

**Android/iOS**

Step 1: Download APK/APP namely "WirelessMedia"  
 Step 2: Connect wireless network WMS-3343 and enter password  
 Step 3: Open the app and click Mirroring to show your mobile screen

3. You have to copy the “Launcher” (PC client software \*.exe) from your USB flash drive on your Laptop/ PC at the first tim and run it to mirror.

### Note:


You do not need Admin-rights for installing the PC client software.

## Method 2. Via USB A/C Dongle

1. Plug USB A/C Dongle to the USB port of WMS to pair for the first time. There is no need to pair from the second time. It will download the “launcher” PC software for Windows and Mac book to the USB A/C Dongle automatically. Unplug USB A/C Dongle after OSD” Succeeded to pair”.



2. Plug USB A/C Dongle to your PC/ Laptop via USB port or type-C port, click the \*.exe. or apk to run for Windows PC/ Mac book.



3. Enter the password which showed on the homepage of WMS. Then click the “Ready to share” to mirror.

### Note:

1. You do not need to click the PC client software from the second time. It will auto run and mirror after the password. And it will not stop mirroring after unplugging WMT-Mini from the PC/ Laptop.
2. Also USB A/C Dongle can be common USB driver to get the “launcher” PC software like Method 1

## Software Status



### Method 3. Via HDMI dongle

1. Plug the USB connector of HDMI dongle to the USB port of WMS to pair at the first time. Unplug HDMI dongle from WMS when see the OSD "Succeeded to pair".



2. Plug the USB and HDMI connector of HDMI dongle to the USB and HDMI port of your PC /Laptop. USB for power and HDMI for AV.
3. Touch to mirror when the LED indicates static green.

#### Note:

Blink green LED means connecting, static green LED means connected, and static red LED means mirroring.

## Smart mobile devices

### For Android Mobile Device.

1. Download APK namely “WirelessMedia” from application store (use QR-code scanner for Home screen) or base unit WMS.
2. Connect your mobile devices’ Wi-Fi with the wireless network of WMS (hotspot: ID and password showed on the homepage)
3. Open the application, select the right device, and click “Share screen” to show your mobile screen.




### For iOS Mobile Device.

1. Download APK namely “WirelessMedia” from application store (use QR-code scanner for Home screen) or base unit WMS.
2. With Airplay technology, user can stream his screen wirelessly to Base-unit.
3. For iOS devices, please swipe from bottom on desktop, to activate the control center. Click the Airplay icon on your Apply device and select the target “WMS-\*\*\*” (ID of Base unit) to start mirroring to the main screen..


# Web Server

1. User can browser the IP to enter the web control to start setting. It need the PC/Laptop and the WMS in the same network. (Wireless or LAN). The IP address is on the right corner of the home-page.
2. User can get the PC software, Mac App, Android Apk from the page as below.






3. Click “Console” to the setting menu. The password is “**admin**” by default to login in.



4. Then you will come to the setting menu and start to set.



**BLANK PAGE**

**BLANK PAGE**

# Support

For more info or tech support  
<http://www.siig.com/support>

Feb, 2020 Copyright © 2020 by SIIG, Inc. All rights reserved.