Package contents

- 10-Port USB-AC & Wireless Charging Station
- Power Adapter 19V/7.8A
- · Ouick Start Guide

Layout



1. Ambient light:

Green: Wireless charging power on or charging finished.

Blue: charging None: Standby

2. Wireless charging area:

For smartphone wireless charging 5V/1A 5W (Max)

3. Open slot:

Holds and organizes tablets, smartphones and other USB powered devices while charging

4. Wireless Switch:

Turn on/off the wireless changing function

5 DC in:

Connects to the included power adapter

6. USB Charging Port A (x6): DC 5V/2.4A (Max)

7. USB Charging Port C (x4): DC 5V/9V/12V 18W (Max)

Notice

- Charging station power output 150W (Max)
- Always Unplug the Charging Station from the power source when not in use
- **DO NOT** place the Charging Station on heated surface or next to other heat sources.

- DO NOT attempt to replace any parts oropen the case of the Charging Station, opening the case can cause personal injury due to electrical hazard and will void themanufacturer warranty
- **DO NOT** expose the Charging Station to liquids or excessive heat
- DO NOT use corrosive cleaning substances on the Charging Station
- **Keep out of** the reach of children
- For optimal charging speed, we recommend using your device's original equipment USB charging cable.

Support

For more info or tech support http://www.siig.com/support

LOT munber



10-port USB-A/C&Wireless Charging Station—150W

Quick Start Guide



