**Read the entire instruction manual before you start installation and assembly. If you have any question regarding any of the instructions or warnings, please contact us.**

## Unpacking

- Carefully remove the contents and lay them out on cardboard or other protective surface
- Check package contents against the parts list to ensure that all components are received undamaged. Do not use damaged or defective parts
- Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, please contact us.

## CAUTION:

Use with products heavier than the rated weights indicate may result in instability causing possible injury.

- Mount must be attached as specified in assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- This product is designed to be installed on wood stud walls, solid concrete walls or brick walls.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

## MAINTENANCE

Check that the bracket is secure and safe to use at regular intervals (at least every three months)

## Support

**For more info or tech support** http://www.siig.com/support

SIIG®

# Aluminum Gas Spring Monitor Wall Mount 17" to 32"

# Installation Guide



P/N: CE-MT2K12-S1
04-1132A








A (x1)

B (x1)

D (x3)

C (x1)

6mm (x1)
E

M4x12 (x4)
M-A

M4x16 (x4)
M-B



M5x12 (x4)
M-C

M5x16 (x4)
M-D

D5 (x4)
M-E

M-F (x4)



W-A (x3)

W-B (x3)

W-C (x3)

## 1a













## 1b









## 2




## 3a




## 3b






## 4