



SATA II PCIe RAID

Quick Installation Guide

Introducing the *SATA II PCIe RAID*

The *SATA II PCIe RAID* is an ultra high-speed two channel Serial ATA Generation II RAID controller for use in PCI Express enabled systems.

Features and Benefits

- Compliant with PCI Express Base Specification 1.0A
- Compliant with Serial ATA 1.0 specifications with support for full complement of SATA II optional features
- PCI Express 1-lane (x1) SATA II adapter works with PCI Express slots with different lane width
- Installs in any available PCI Express slot and supports data transfer rates up to 3.0Gbps (300MBps)
- Spare enhanced low profile bracket is included to work in low profile chassis
- Supports Native Command Queuing (NCQ), Non-zero offsets NCQ, and Out-of-order data delivery NCQ
- Independent command fetch, scatter/gather, and command execution
- Supports RAID 0 (striping) and RAID 1 (mirroring) for speed and data protection respectively

System Requirements

- PCI Express-enabled system with one available PCI Express slot
- Windows 2000/XP/Server 2003

Package Contents

- *SATA II PCIe RAID* adapter
- Spare enhanced low profile bracket
- 2 Serial ATA data cables
- Dual-connector Serial ATA power cable
- "Y" split power cable
- Driver software CD
- This quick installation guide

Layout




Figure 1. SATA II PCIe RAID layout

*** Note:** Connect the hard disk drive activity LED of the system case to the pins horizontally. This connection is optional.

Hardware Installation

General instructions for installing the card are provided below. Since the design of computer cases and motherboards vary, refer to your computer's reference manual for further information, if needed.

Static Electricity Discharge may permanently damage your system. Discharge any static electricity build up in your body by touching your computer's case for a few seconds. Avoid any contact with internal parts and handle cards only by their external edges.

1. Turn OFF the power to your computer and any other connected peripheral devices.
2. Unplug the power cord from the back of the computer.
3. Remove your computer's cover.
4. Remove the slot bracket from an available PCI Express slot.
5. To install the card, carefully align the card's bus connector with the selected PCI Express slot on the motherboard. Push the board down firmly, but gently, until it is well seated.
6. Replace the slot bracket's holding screw to secure the card.
7. Now go to **Device Connection** to connect your Serial ATA hard disk drives.

Device Connection

The *SATA II PCIe RAID* is a two channel Serial ATA controller that supports two Serial ATA hard disk drives. It is recommended to use identical hard drives for all RAID configurations, however, it's possible to combine hard drives of different sizes and makes.

1. Install your hard disk drive(s) in chassis.
2. Connect the Serial ATA hard disk drive to the system power supply using the included *Dual Connector Serial ATA power cable*.

Note: For hard drives with both SATA power connector and legacy 5-pin connector, use either the SATA power connector or the legacy 5-pin power connector. Using both power connectors may damage the hard drive.

3. Connect one end of the *Serial ATA cable* to the hard disk drive.



Figure 2. Hard disk drive connections

4. Attach the other end of the *Serial ATA data cable* to the Serial ATA connector on the *SATA II PCIe RAID*.



Figure 3. Connecting the Serial ATA data cable(s)

5. Follow the same instructions to connect the second hard drive. Device connection is now complete.

Note: If it is your desire to monitor disk activity of the Serial ATA hard drives, you may at this time connect the hard disk LED of the system case to the **Hard Disk LED Pins** on the Serial ATA controller.



Figure 4. Connecting HDD LED

6. Replace the computer cover and reconnect the power cord. Go to **RAID Arrays** to configure the RAID BIOS.

RAID Arrays

RAID Arrays are setup in the *SATA II PCIe RAID's* BIOS. Find your RAID set from the table of contents.

Table of Contents

| | |
|--------------------------------------|----------|
| RAID 0 (striping) | page 6-7 |
| RAID 1 (mirroring) | page 7-8 |
| Rebuilding a Failed Mirror Set | page 8-9 |
| Deleting RAID Arrays | page 9 |
| Resolving Conflicts | page 10 |
| Low Level Format | page 10 |
| Logical Drive Info | page 10 |

RAID 0 (Striping)

This RAID array to be used on **New/Blank** hard drives. Striping will destroy existing data on the hard drive. **Auto Configuration** is recommended. For applications that require custom chunk size, **Manual Configuration** is offered.

Auto Configuration (recommended)

The default chunk size is **64k** when selecting **Auto configuration**.

1. As the BIOS boots press **Ctrl+S** or **F4** when prompted to enter the **RAID BIOS**.
2. At the next screen select **Create RAID Set**, then press **Enter**.
3. Select **RAID0**, then press **Enter**.
4. Select **Auto configuration**, then press **Enter**.
5. Input the RAID size, press **Enter**.
6. When asked **Are You Sure (Y/N)?**, press **Y** to accept.
7. Press **Ctrl+E** to exit the BIOS.
8. When asked **Are you sure to exit (Y/N)?**, press **Y** to exit and reboot.
9. Continue with Fdisk and Format steps as if you were installing a conventional hard drive.

Manual Configuration

1. As the BIOS boots press **Ctrl+S** or **F4** when prompted to enter the **RAID BIOS**.
2. At the next screen select **Create RAID Set**, then press **Enter**.
3. Select **RAID0**, then press **Enter**.
4. Select **Manual configuration** then press **Enter**.

5. Select chunk size from **8k, 16k, 32k, 64k** or **128k**, then press **Enter**.
6. Select the **first drive**, press **Enter**.
7. Select the **second drive**, press **Enter**.
8. Input the RAID size, press **Enter**.
9. When asked **Are You Sure (Y/N)?**, press **Y** to accept.
10. Press **Ctrl+E** to exit the BIOS.
11. When asked **Are you sure to exit (Y/N)?**, press **Y** to exit and reboot.
12. Continue with Fdisk and Format steps as if you were installing a conventional hard drive.

RAID 1 (Mirror)

For New/Blank Hard Drives

1. As the BIOS boots press **Ctrl+S** or **F4** when prompted to enter the **RAID BIOS**.
2. At the next screen select **Create RAID Set**, then press **Enter**.
3. At the next screen select **RAID1** then press **Enter**.
4. Select **Auto configuration**, then press **Enter**.
5. Input the RAID size, press **Enter**.
6. When asked **Are You Sure (Y/N)?**, press **Y** to accept.
7. Press **Ctrl+E** to exit the BIOS.
8. When asked **Are you sure to exit (Y/N)?**, press **Y** to exit and reboot.
9. Continue with Fdisk and Format steps as if you were installing a conventional hard drive.

For Existing Hard Drives with Data

1. As the BIOS boots press **Ctrl+S** or **F4** when prompted to enter the **RAID BIOS**.

2. At the next screen select **Create RAID Set**, then press **Enter**.
3. At the next screen select **RAID1** then press **Enter**.
4. Select **Manual configuration**, then press **Enter**.
5. Select the **Source** drive, press **Enter**.
6. Select the **Target** drive, press **Enter**.
7. Select **Create with data copy**, then press **Enter**.
8. Select **online copy**, then press **Enter**.

Note: Selecting **Online Copy** builds the mirror while in Windows. Selecting **Offline Copy** builds the mirror before exiting the RAID BIOS.

9. Input the RAID size, press **Enter**.
10. Press **Ctrl+E** to exit the BIOS.
11. When asked **Are you sure to exit (Y/N)?**, press **Y** to exit and reboot.

Rebuilding a Failed Mirror Set

When a failure to one member occurs, you will be notified either by the **RAID BIOS** during boot or by the **SATA Raid5 GUI** while in Windows. The steps below will guide you in rebuilding a failed mirror set.

For Offline Mirror Rebuild (SATA RAID BIOS)

1. Replace the failed drive(s) with one of equal or greater capacity, then start the computer.
2. During boot press **Ctrl+S** or **F4** to enter the **RAID BIOS**.
3. Select **Create RAID Set** press **Enter**.
4. Select **SPARE DRIVE**, then press **Enter**.
5. Select the single hard drive then press **Enter**.

6. Input the RAID size, press **Enter**. When asked **Are You Sure (Y/N)?**, press **Y** to confirm.
7. Select **Rebuild Raid 1 Set**, press **Enter**.
8. When asked **Are you sure (Y/N)?**, press **Y** confirm. The mirror will begin rebuilding. Do not interfere with the process.
9. When rebuilding is finished, press **Ctrl+E**.
10. When asked **Are you sure to exit (Y/N)?**, press **Y** to exit and reboot.

For Online Mirror Rebuild (in Windows)

1. Replace the failed drive(s) with one of equal or greater capacity, then start the computer.
2. When Windows resumes, at the SATA SoftRaid 5 screen, click **Legacy Support, Rebuild Legacy RAID Group**.

Note: If **Legacy Support** does not show, click **File, Configuration, Advanced Options**. Check **Legacy (Bootable) Support**, then click **OK**.

3. At **Rebuild Legacy RAID Group** box, select both hard drives, click **Rebuild**.
4. Click **OK**, click **Cancel** to close the window.
5. The mirror will rebuild. Rebuild time is dependant on the size of the mirror set.

Deleting RAID Arrays

1. As the BIOS boots press **Ctrl+S** or **F4** when prompted to enter the **RAID BIOS**.
2. Select **Delete RAID Set**, then press **Enter**.
3. Select the RAID set then press **Enter**.
4. When asked **Are You Sure (Y/N)?**, press **Y** to confirm.

Resolving Conflicts

When a RAID set is created, the metadata written to the disk includes drive connection information. If, after a disk failure, the replacement disk was previously part of a RAID set (or used in another system), it may have conflicting metadata. If so, this will prohibit the RAID set from being either created or rebuilt, in order for the RAID set to function properly, this old metadata must be first overwritten with the new metadata. To resolve this, from the main BIOS window select **Resolve Conflicts**, then press **Enter**, the correct metadata, including the correct drive connection information, will be written to the replacement disk.

Low Level Format

Low Level Format is built into the RAID BIOS to make it more convenient to erase the entire contents of a hard disk drive, including data, drive and partition information. The Low Level Format utility works on single hard drives only, before the RAID set is configured.

Logical Drive Info

This menu item allows the display of the assignment of physical drives within a logical set (RAID0, RAID1, etc.). This is a display only function.

Software Installation

This section provides information on how to install the *SATA II PCIe RAID* drivers.

Table of Contents

| | |
|-----------------------------------|------------|
| Windows 2000 | page 11-12 |
| Windows XP/Server2003 | page 12-13 |
| Verify Windows Installation | page 14 |

Windows 2000

For A New Installation

A new installation of Windows 2000 requires a floppy disk for the driver installation. To make this floppy disk, copy the **contents** of the **Floppy** folder, found on the driver CD, onto a blank floppy disk then follow the directions below.

1. Setup the RAID array prior to Windows installation.
2. Follow Windows 2000 installation procedure.
3. Restart the computer when prompted by the installation.
4. At the **Windows 2000 Setup** screen, press **F6** to install the RAID driver.
5. When prompted, press **S** to specify the location of the driver.
6. Insert the floppy disk, then press **Enter**.
7. Select **Silicon Image Sil 3132 SoftRaid 5 Controller for Windows 2000**, then press **Enter**.
8. Press **Enter** again to finish driver installation, then follow the on-screen instructions to complete the Windows installation.

When Windows installation completes, go to **SATARaid5 GUI** on page 14 and install the RAID utility.

For An Existing Installation

1. Setup the RAID array prior to driver installation and boot up to Windows.
2. At **Found New Hardware Wizard**, click **Next**.
3. Select **Search for a suitable driver for my device (recommended)**, then click **Next**.
4. Insert the driver CD, check **CD-ROM drives**, uncheck the other boxes, click **Next**, then click **Next** again.
5. If the **Digital Signature Not Found** message appears, click **Yes**. *Our driver has been thoroughly tested for stability and compatibility.*
6. Click **Next**, then **Finish**.
7. Repeat steps 2-6.
8. Click **Yes** to restart to complete the installation.

When Windows resumes, go to **SATA RAID 5 GUI** on page 14 and install the RAID utility.

Windows XP/Server 2003

For A New Installation

A new installation requires a floppy disk for the driver installation. To make this floppy disk, copy the **contents** of the **Floppy** folder, found on the driver CD, onto a blank floppy disk then follow the directions below.

1. Setup the RAID array prior to Windows installation.
2. Follow Microsoft's Windows installation procedure.
3. Restart the computer when prompted by Windows' installation.
4. At the **Windows Setup** screen, press **F6** to install the RAID driver.

5. When prompted, press **S** to specify the location of the driver.
6. Insert the floppy disk, then press **Enter**.
7. Select **Silicon Image Sil 3132 SoftRaid 5 Controller for Windows XP/Server 2003**, then press **Enter**.
8. Press **Enter** to finish driver installation, then follow the on-screen instructions to complete the Windows installation.

Note: If the **Security Alert** warning pops up, click **Yes**. *Our driver has passed Microsoft compatibility testing, this message appears during new installation.*

When Windows installation completes, go to **SATARaid5 GUI** on page 14 and install the RAID utility.

For An Existing Installation

1. Setup the RAID array prior to driver installation and boot up to Windows.
2. At the **Found New Hardware Wizard**:
XP (w/SP1 or earlier)/Server 2003: continue to step #3
XP (w/SP2 or later)/Server 2003 (w/SP1 or later): select **No, not at this time**, then click **Next**.
3. Insert the driver CD, select **Install the software automatically (Recommended)**, and click **Next**.
4. Accept the default entry, then click **Next**.
5. Click **Finish**.
6. Repeat steps 2-5.
7. Click **Yes** to restart to complete the installation.

When Windows resumes, go to **SATARaid5 GUI** on page 14 and install the RAID utility.

To Verify Windows 2000/XP/2003 Installation

1. Right click **My Computer** and click **Manage**.
2. Select **Device Manager**.
3. Double click **SCSI and RAID controllers**, then double click **Silicon Image Sil 3132 SoftRaid 5 Controller** to display driver properties. A message *This device is working properly* is displayed in the dialog box, the driver has been correctly installed.

SATAraid5 GUI


The SATAraid5 GUI provides the user an easy way to monitor your RAID set.

Installing SATAraid5 GUI

1. Place the driver installation CD into the CD-ROM drive.
2. At the Windows desktop click **Start**, then **Run**.
3. Type **D:\Setup.exe**, then click **OK**. (Change **D:** to match your CD-ROM drive letter)
4. Click **Next**, then click **Next** again.
5. At the **Select Components** box, uncheck **RAID5 Driver**, then click **Next**.
6. Follow the on-screen instructions to complete the installation.

SATAraid5 GUI Overview

The installation program configures the SATAraid5 GUI to automatically start when Windows is started. If the GUI does not automatically start or is closed by the user, choose the SATAraid5 program from the start menu to launch the program. Upon launching the GUI, the main window should appear similar to the following.



RAID Groups
window

Device Configuration
window

RAID Groups window

This window identifies SATA host adapters and configured RAID groups. Selecting each RAID group in the RAID Groups window, members consisting of the RAID group will be highlighted in the Device Configuration window.

Right clicking on each node in the RAID Groups window, a popup menu will be displayed to let the user select an action to be performed for the selected controller or RAID group.

Device Configuration window

This window identifies all physical drives and their partitions. A physical drive can be partitioned into several portions and each portion can be a RAID group member.

SATARAID5 Configuration Menu

SATARAID5 configuration menu includes customization of the settings for Log File, Popup and Advanced Options. By clicking on File, then Configuration, the user may customize the settings for Log File, Popup and Advanced Options tabs.



Log File

The log file is used to store event information received from all the RAID drivers. The log file can be viewed with any text viewer (such as Notepad) or with the Event Log window of SATARAID5 GUI. Use the Log File tab to enable/disable the log file, set where the log file should be stored and the name of the file as well.

Popup

The popup window is a visual notification that an event has occurred. The popup window can be disabled or set to popup for only certain event levels.

The different levels are:

Informational - The popup window will be displayed for the following events:

- Informational
- Warnings
- Errors

Warning - The popup window will be displayed for the following events:

- Warnings
- Errors

Errors - The popup window will be displayed for the following events:

- Errors

Disabled - No popup will occur

Advanced Options

The advanced options tab is used to control advanced features of the RAID driver. By default, all advanced options are disabled.

Legacy (Bootable) Support: When this feature is selected, Legacy Support menu will be available in the menu bar. The Legacy Support menu includes a list of menu items to support RAID functions for legacy RAID groups.

Delete Member Support: When this feature is selected, Delete Member menu item will be available under the Device menu. The Delete Member menu item allows the user to delete a member from RAID 1 group.

Advanced RAID Features: When this feature is selected and the user selects to create RAID group, if the RAID group to be created is fault tolerant group (RAID1), the user will be able to select Improper Shutdown Policy in the Create RAID Group dialog box. The Advanced RAID Features are not supported for Legacy RAID groups.

Resources Info Support: When this feature is selected, Resources menu item will be available under the Window menu. This feature is for debugging purpose only.

Device Menu Commands

Create Spare and Delete Spare

This command displays a dialog box to let the user create or delete a spare drive. This feature is not used with the *SATA II PCIe RAID*.

Delete Member

This command displays a dialog box to let the user choose RAID groups' members to delete. Since RAID 0 is not fault-tolerant, RAID 0 members will not be shown in the list.

Delete Orphan

An orphan device segment is part of a RAID group that cannot access another device segment within the same RAID group. When a member of a RAID group fails (such as a loss of power or a complete hard disk failure), it becomes an orphan. This command displays the Delete Orphan Segment window to show all orphan segments and allows the user to delete selected orphan segments.

Device Summary

This command displays the Segment Summary window to show all physical devices' segments.

RAID Group Menu Commands

Create RAID Group

This command displays a dialog box to let user create a RAID group, the user needs to specify the following parameters:

RAID Group Label: Provides a name for the RAID group.

RAID Group: Select a group ID from the available ID list.

Configuration:

Striped: for RAID 0; *Mirrored:* for RAID 1

Capacity: Select from a list of RAID group sizes. Selecting MAX will create the largest RAID set possible with the drives selected.

Chunk Size: Select one size from the available list. This setting is for RAID 0 (Stripe) set only.

Rebuild Priority: Select from the available list. RAID 0 and virtual disk do not require this. 10 is the highest level of rebuild priority which means that rebuild times will be faster but will take more CPU resources to rebuild.

Devices: Select RAID member devices from the available device segment list.

Rebuild RAID Group

This command displays a dialog box to let the user choose a replacement segment to rebuild a non-fault tolerant RAID group.

Delete RAID Group

This command displays a dialog box to let the user choose RAID groups to delete.

RAID Group Summary

This command displays a dialog box to show all RAID groups' group ID, configuration and status. The RAID Group Summary window has it's own menu bar. All options available via the menu bar are shown below.

Sorting: This command displays a dialog box to let the user choose up to 3 items to sort RAID group items in the RAID Group Summary window.

Fields: This command displays a dialog box to let the user choose which fields will be shown in the RAID Group Summary window.

Window Menu Commands

Task Manager

This command displays the Task Manager window. The Task Manager window list all RAID and disk management tasks that have been started and/or done. This window provides the user with the ability to schedule any RAID and disk management operations including RAID group creation, rebuild and test. The Task Manager window has it's own menu bar. All options available via the menu bar are shown below.

Open, Save and Print: These options will be available in future revisions.

Sorting: This command displays a dialog box to let the user choose up to 3 items to sort task items in the task list.

Fields: This command displays a dialog box to let the user choose which fields will be shown in the task list.

Modify: This command allows the user to modify parameters of the selected task items.

Suspend: This command allows the user to suspend the selected task items.

Resume: This command allows the user to resume the suspended task items.

Cancel: This command allows the user to cancel the selected task items.

Delete: This command displays a dialog box to let the user delete the selected task items.

Event Log

This command displays the Event Log window. The Event Log window displays SATA device-related events that occur while SATARAID5 GUI is running. The Event Log window has it's own menu bar. All options available via the menu bar are shown below.

Sorting: This command displays a dialog box to the the user choose up to 3 items to sort event items in the event log.

Fields: This command displays a dialog box to let the user choose which fields will be shown in the event log.

Resources

This command displays the Resources Information window. This feature is for debugging purpose only.

Legacy Support Menu Commands

Create Legacy RAID Group

This command displays a dialog box to let the user create legacy (bootable) RAID groups. This item is disabled if new RAID groups exist. The parameters are discussed below.

RAID Group: Selects a group ID from the available list.

Configuration:

Striped: for RAID 0; *Mirrored:* for RAID 1

Capacity: Select from a list of RAID group sizes.

Chunk Size: Select one value from the available list.

Rebuild Priority: Select from the available list. RAID 0 and virtual disk do not require this. 10 is the highest level of rebuild priority which means that rebuild times will be faster but will take more CPU resources to rebuild.

Devices: Select RAID member devices from the available device segment list.

Rebuild Legacy RAID Group

This command displays a dialog box to let the user choose a replacement segment to rebuild a non-fault tolerant legacy RAID group.

Delete Legacy RAID Group

This command displays a dialog box to let the user choose legacy RAID groups to delete. This item is disabled if no legacy RAID group exists.

Convert Legacy RAID Group

This command displays a dialog box to let the user choose legacy RAID groups to convert to new RAID groups of the same RAID type. This item is disabled if no legacy RAID group exists.

Create/Delete/Convert Legacy Spare

These commands display a dialog box to let the user configure a legacy spare. These features are not used with the *SATA II PCIe RAID*.

Technical Support and Warranty

QUESTIONS? SIIG's **Online Support** has answers! Simply visit our website at www.siig.com and click on **Support**. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and one of our technical support analysts will promptly respond.

A lifetime manufacturer warranty supplied with this product is offered by SIIG, Inc. Please see SIIG website for more warranty details. If you should happen to encounter any problems with this product, please follow the procedures below.

If it is within the store's return policy period, please return the product to the store where you purchased from.

If your purchase has passed the store's return policy period, please follow these steps to have the product repaired or replaced.

Step 1: Submit your RMA request.

Go to www.siig.com, click **Support**, then **RMA** to submit a request to [SIIG RMA](#). If the product is determined to be defective, an RMA number will be issued. SIIG RMA department can also be reached at (510)413-5333.

Step 2: After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All software, cable(s) and any other accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG will refuse to accept any shipping package, and will not be responsible for a product returned without an RMA number posted on the outside of the shipping carton.
- You are responsible for the cost of shipping the product to SIIG at the following address:

SIIG, Inc.
6078 Stewart Avenue
Fremont, CA 94538
RMA #: _____

- SIIG will ship the repaired or replaced product via Ground in the U.S and International Economy outside of the U.S at no cost to the customer.

About SIIG, Inc.

Founded in 1985, SIIG, Inc. is a leading computer upgrade manufacturer of I/O connectivity products, including PCI & ISA serial and parallel ports, USB, Serial ATA & UltraATA controllers, FireWire (1394a/b), Networking, Sound Cards, and other accessories. SIIG is the premier one-stop source of upgrades.

SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High-quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, and e-commerce sites in the Americas and the UK, as well as through major distributors, system integrators, and VARs.

PRODUCT NAME

SATA II PCIe RAID

FCC RULES: TESTED TO COMPLY WITH FCC PART 15,
CLASS B OPERATING ENVIRONMENT: FOR HOME OR
OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.
6078 Stewart Ave.
Fremont, CA 94538-3152

SATA II PCIe RAID is a trademark of SIIG, Inc. SIIG and SIIG logo are registered trademarks of SIIG, Inc. Microsoft and Windows are registered trademarks of Microsoft Corporation. Other names used in this publication are for identification only and may be trademarks of their respective companies.