

# Parallel PCI 1P

## Quick Installation Guide

### Introducing the *Parallel PCI 1P*

---

The *Parallel PCI 1P* high-speed parallel card provides one additional parallel port to your system. Depending on the model purchased, this board will fit into either Full or Low Profile chassis.

### Features and Benefits

- Conforms to PCI v2.2 Plug and Play
- Supports 32-/64-bit, 3.3V/5V PCI and PCI-X slots
- Full support for Windows-based software
- Reduces CPU load and improves system performance dramatically
- Supports EPP/ECP, BPP (bi-directional), SPP (standard) parallel port modes

### System Requirements

- Pentium or equivalent computer with an available 32-/64-bit PCI or PCI-X slot
- Windows<sup>®</sup> 95/98/98SE/ME/NT 4.0/2000/XP (32-/64-bit)/Server 2003 (32-/64-bit)/Vista (32-/64-bit)

### Package Contents

- *Parallel PCI 1P* board
- Low profile bracket (for *Dual Profile PCI-1P* only)
- Driver CD
- This quick installation guide

## Layout

Depending on the model purchased, the bracket mounted on your board may vary from the image displayed.




Figure 1. Layout

## Hardware Installation

---

General instructions for installing the card are provided below. Since the design of computer cases and motherboards vary, refer to your computer's reference manual for further information, if needed.

Static Electricity Discharge may permanently damage your system. Discharge any static electricity build up in your body by touching your computer's case for a few seconds. Avoid any contact with internal parts and handle cards only by their external edges.

1. Turn OFF the power to your computer and any other connected peripheral devices.
2. Unplug the power cord from the back of the computer.

3. Remove your computer's cover.
4. Remove the slot bracket from an available PCI slot.
5. To install the card, carefully align the card's bus connector with the selected PCI slot on the motherboard. Push the board down firmly, but gently, until it is well seated.
6. Replace the slot bracket holding screw to secure the card.
7. Replace the computer cover and reconnect the power cord.

## **Driver Installation**

---

This section provides information on how to install the *CyberParallel* PCI drivers.

### **Windows 95**

1. At the **Update Device Driver Wizard**, click **Next**.
2. Insert the driver CD, and click **Other Locations**. Type in **D:\9x**, click **OK**, then **Finish**. (Change **D:** to match your CD-ROM drive letter)
3. From the **Insert Disk** window, click **OK**. When the **Copying Files** dialog box appears, type in **D:\9x**, then click **OK**. (Change **D:** to match your CD-ROM drive letter)
4. Restart Windows to complete the installation.

### **Windows 98/98SE**

1. At the **Add New Hardware Wizard**, click **Next**.
2. Select **Search for the best driver for your device. (Recommended)**, then click **Next**.

3. Select **Specify a location**, uncheck the other boxes, insert the driver CD, type in **D:\9x**, then click **Next**. (Change **D:** to match your CD-ROM drive letter)
4. Click **Next**, then **Finish**. If prompted, at the **Insert Disk** box click **OK**. Insert your Windows 98 Installation CD-ROM then click **OK**.
5. Restart Windows to complete the installation.

## **Windows ME**

1. At the **Add New Hardware Wizard**, select **Specify the location of the driver (Advanced)**, then click **Next**.
2. Check **Specify a location**, uncheck the other box, insert the driver CD, type in **D:\Me**, then click **Next**. (Change **D:** to match your CD-ROM drive letter)
3. Click **Next**, then **Finish**.
4. Restart Windows to complete the installation.

## **To Verify Windows 95/98/98SE/ME Installation**

1. From the main desktop, double click **My Computer**, **Control Panel**, **System**, then click **Device Manager**.
2. Double click **Ports (COM & LPT)**, **ECP Printer Port...** and **SIIG CyberPro Parallel port** should be displayed.

## **Windows NT 4.0**

1. From the desktop click **Start**, then **Run**.
2. Insert the driver CD, type in **D:\NT4\Install\_Parallel.exe**, then click **OK**. (Change **D:** to match your CD-ROM drive letter)

3. At the **Welcome** window, click **Next**.
4. Choose **Install**, then click **Next**.
5. Click **Yes**, then click **Exit**.
6. Click **Yes** to restart to complete the installation.

### **To Verify Windows NT 4.0 Installation**

1. Click **Start, Programs, Administrative Tools**, then **Windows NT Diagnostics**.
2. Click **Resources** tab, **SIIGpar** should be displayed.

### **Windows 2000**

1. At the **Found New Hardware Wizard**, click **Next**.
2. Select **Search for a suitable driver for my device (recommended)**, then click **Next**.
3. Select **Specify a location**, uncheck the other options and click **Next**.
4. Insert the driver CD, type in **D:\2000**, then click **OK**. (Change **D:** to match your CD-ROM drive letter)
5. Click **Next**, then click **Finish**.
6. Restart Windows to complete the installation.

### **To Verify Windows 2000 Installation**

1. Right click **My Computer**, click **Manage**, then click **Device Manager**.
2. Click on the + (plus sign) in front of **Ports (COM & LPT)**, **SIIG CyberPro Parallel port...** should be displayed.

## 32-bit Windows XP/Server 2003

1. At the **Found New Hardware Wizard**, insert the driver CD.  
*For XP w/SP1 or earlier/ Server 2003: go to step #2.*  
*For XP w/SP2 or later/Server 2003 wSP1 or later: select **No, not this time**, click **Next**.*
2. Select **Install the software automatically (Recommended)**, then click **Next**.
3. Click **Finish**.
4. Repeat steps 1-3 two more times.
5. Restart Windows to complete the installation.

## 64-bit Windows XP/Server 2003

1. At the **Found New Hardware Wizard**, insert the driver CD.  
*For XP w/SP1 or earlier/ Server 2003: go to step #2.*  
*For XP w/SP2 or later/Server 2003 wSP1 or later: select **No, not this time**, click **Next**.*
2. Select **Install the software automatically (Recommended)**, then click **Next**.
3. Click **Continue Anyway**, then click **Finish**.
4. Repeat steps 1-3 several more times.
5. Restart Windows to complete the installation.

## To Verify Windows XP/Server 2003 Installation

1. Right click **My Computer**, click **Manage**, then click **Device Manager**.
2. Click on the + (plus sign) in front of **Ports (COM & LPT)**, **SIIG CyberPro Parallel port...** should be displayed.

## Windows Vista™

1. At the **Found New Hardware** window, insert the driver CD, click **Locate and install driver software (recommended)**, then click **Continue**.

**Note:** Windows Vista driver installation process may take several minutes to complete.

2. Click **Next**, then click **Close** to complete the installation.

## To Verify Windows Vista Installation

1. Right click **Computer**, click **Manage**, click **Continue**, then click **Device Manager**.
2. Click on the + (plus sign) in front of **Ports (COM & LPT)**, **SIIG CyberPro Parallel port...** should be displayed.

**Blank Page**



**Blank Page**

**Blank Page**

## Technical Support and Warranty

---

**QUESTIONS?** SIIG's **Online Support** has answers! Simply visit our web site at [www.siig.com](http://www.siig.com) and click **Support**. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and a technical support analysts will promptly respond.

SIIG offers a lifetime manufacturer warranty with this product. Please see our web site for more warranty details. If you encounter any problems with this product, please follow the procedures below.

A) If it is within the store's return policy period, please return the product to the store where you purchased from.

B) If your purchase has passed the store's return policy period, please follow these steps to have the product repaired or replaced.

**Step 1:** Submit your RMA request.

Go to [www.siig.com](http://www.siig.com), click **Support**, then **RMA** to submit a request to [SIIG RMA](#). If the product is determined to be defective, an RMA number will be issued. SIIG RMA department can also be reached at (510) 413-5333.

**Step 2:** After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All software, cable(s) and any other accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG will refuse to accept any shipping package, and will not be responsible for a product returned without an RMA number posted on the outside of the shipping carton.
- You are responsible for the cost of shipping. Ship the product to the following address:

**SIIG, Inc.**  
**6078 Stewart Avenue**  
**Fremont, CA 94538-3152, USA**  
**RMA #: \_\_\_\_\_**

- SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

## About SIIG, Inc.

---

Founded in 1985, SIIG, Inc. is a leading computer upgrade manufacturer of I/O connectivity products, including PCI & ISA serial and parallel ports, USB, Serial ATA & UltraATA controllers, FireWire (1394a/b), networking, sound cards, and other accessories. SIIG is the premier one-stop source of upgrades.

SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High-quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, through major distributors, system integrators, and VARs in the Americas and the UK, and through e-commerce sites.

### **PRODUCT NAME**

Parallel PCI 1P

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS B OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

### **FCC COMPLIANCE STATEMENT:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE

SIIG, Inc.  
6078 Stewart Avenue  
Fremont, CA 94538-3152, USA

Parallel PCI 1P is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation. Pentium is a registered trademark of Intel Corporation. Other names used in this publication are for identification only and may be trademarks of their respective companies.