

Cordless Rechargeable LED Folding Light Quick Reference Guide



Introduction

SIIG's *Cordless Rechargeable LED Folding Light* features trifold design and rechargeable battery for portability and ease of use. It integrates 18 LEDs with adjustable light output, multi-function clock/alarm/temperature display, battery charge/power status LED and is wall mountable. This portable cordless rechargeable LED light is the prefect solution for your on-the-go or at home lighting needs.

Package Contents

- Cordless Rechargeable LED Folding Light
- Mini USB charging cable
- Wall mount bracket
- Carrying pouch
- Quick reference guide

Layout




Figure 1: Layout

1. LED Lights

18 LEDs with output up to 108 Lumens. Color Temperature: 5500K(Daylight Color)

2. One-Touch Dimmer Switch

Touch the switch to adjust the LED light brightness or tap once to turn the power on or off.



Figure 2: One-Touch Dimmer Switch

3. Mounting Holes

To be hooked up with **Wall mount bracket** when mounting the *LED Light* to wall.

4. Time/Temperature Display

Displays the time, day, date, temperature or the alarm settings here



Figure 3

5. Display Settings Buttons

Press the buttons to change the alarm or time/date/ day setting

6. CR2025 Battery Compartment

Powers the Time/Temperature display via CR2025 battery

7. Mini USB Charging Port

Connect to USB power source to charge the internal rechargeable battery

8. Charging Status LED

The indicator of the charging status



Figure 4

Instructions for Use

Charging the LED Light

1. Plug the mini USB tip of included mini USB charging cable into the *LED Light*'s mini USB charging port, then plug the other end of the charging cable into either a USB port of your computer or a USB wall charger. The charge status LED will turn red to indicate the charging process has begun.

NOTE: Please use the included **Mini USB charging cable** to charge the *LED Light*. Using a different USB cable is not recommended.




Figure 5

2. When charging status LED goes off, it indicates the charging process is complete and the mini USB charging cable can be unplugged now.

NOTE: Suggest to have the *LED Folding Light* fully charged before initial use.

LED Light Adjustment

Use the **One-Touch Dimmer Switch** to adjust the brightness as needed.

- Tap the **One-Touch Dimmer Switch** to turn on/turn off the light
- Touch and hold the **One-Touch Dimmer Switch** to turn up/turn down the brightness

NOTE: If the LED light output gradually dim during use, it's a sign of low battery. Please have the *LED Light* recharged.

Display Settings

Before initial use, please remove the CR2025 Battery protection tab to power on the **Time and Temperature Display**. See **Figure 6**.

For future battery replacement, rotate the battery cover clockwise using a coin-shaped object to remove it. Insert a new CR2025 battery with the positive side facing up, then reinstall the battery cover by turning it counterclockwise. See **Figure 7**.



Figure 6





Buttons Definition



MODE	MODE switching button Switch the mode between "Time display mode" and "Alarm mode"
SET	"Start setting" or "Enter"
UP	"Select forward" or "12-hour/24-hour switch"
DOWN	"Select backward" or "Fahrenheit/Celsius switch"

Time display mode setting

- 1. Press the **MODE** button to change to time display mode, a "TIME" would appear at the upper display.
- 2. Press the **SET** button, the number in the editable area will start blinking.
- 3. Press the **UP** or **DOWN** button to select forward or backward, then press the **SET** button to enter.

- 4. Repeat step 3 to set hour/minute/month/date/year in order.
- 5. After setup is completesd, the value on display stops blinking. Click the **UP** button to set the time display format as 12-hour or 24-hour.
- 6. Click **DOWN** button to select between Fahrenheit and Celsius temperature display.

Alarm mode setting

- 1. Press the **MODE** button to change to alarm mode. A symbol of clock would appear at the upper display.
- 2. Press the **SET** button, the number in the editable area will start blinking.
- 3. Press the **UP** or **DOWN** button to select forward or backward, then press the **SET** button to enter.
- 4. Repeat step 3 to set the alarm hour/minute/snooze mode interval**/ring tone in order.
 ** When snooze function is enabled, the alarm will ring for 1 minute on a regular interval.
- 5. After setup, the *LED Light* will ring at the appointed time. Press the **SET** button to turn off the alarm.

Application

Wall Mount

1. Have the hook opening of the included **Wall mount bracket** face upward, tear off the back protective cover from the adhesive tape, then press and hold the adhesive face to the wall for 5-10 seconds.

NOTE: For best adhesion, make sure to clean the wall surface before attaching the bracket to the wall.




Figure 8

2. Have the Mini USB Charging Port of the LED Light face upward, line up the two bottom Mounting Holes to the hooks of the Wall mount bracket, then hook the LED Light on. See Figure 9a.

Pull down the *LED Light* firmly, but gently, to make sure the *LED Light* is hooked onto the **Wall mount bracket** securely. See **Figure 9b**.




Figure 9b

Desktop

When using the *LED Light*, hold the base stand by one hand, and pull up or press down the upper light arm by another hand to the best angle to fit your needs.

NOTE: There's a sensor on the back of the base stand (See **Figure 10a**). If the unit is fully folded, the LED lights turn off automatically (See **Figure 10b**).





Figure 10b

Fully folded

The tri-fold LED light could be fully folded to the smallest size and is convenient to carry around.



Figure 11

Blank Page

Technical Support and Warranty

QUESTIONS? SIIG's **Online Support** has answers! Simply visit our web site at *www.siig.com* and click **Support**. Our online support database is updated daily with new drivers and solutions. Answers to your questions could be just a few clicks away. You can also submit questions online and a technical support analyst will promptly respond.

SIIG offers a 2-year manufacturer warranty with this product. This warranty covers the original purchaser and guarantees the product to be free of any defects in materials or workmanship for two (2) years from the date of purchase of the product.

SIIG will, at our discretion, repair or replace (with an identical product or product having similar features and functionality) the product if defective in materials or workmanship. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Please see our web site for more warranty details.

If you encounter any problems with this product, please follow the procedures below.

A) If it is within the store's return policy period, please return the product to the store where you purchased from.

B) If your purchase has passed the store's return policy period, please follow the steps below to have the product repaired or replaced.

Step 1: Submit your RMA request.

Gotowww.siig.com,clickSupport, then REQUEST A PRODUCT REPLACEMENT to submit a request to <u>SIIG RMA</u> or fax a request to 510-657-5962. Your RMA request will be processed, if the product is determined to be defective, an RMA number will be issued.

Step 2: After obtaining an RMA number, ship the product.

- Properly pack the product for shipping. All accessories that came with the original package must be included.
- Clearly write your RMA number on the top of the returned package. SIIG
 will refuse to accept any shipping package, and will not be responsible for
 a product returned without an RMA number posted on the outside of the
 shipping carton.
- You are responsible for the cost of shipping to SIIG. Ship the product to the following address:

SIIG, Inc. 6078 Stewart Avenue Fremont, CA 94538-3152, USA RMA#:

• SIIG will ship the repaired or replaced product via Ground in the U.S. and International Economy outside of the U.S. at no cost to the customer.

About SIIG, Inc.

Founded in 1985, SIIG, Inc. is a leading manufacturer of IT connectivity solutions (including Serial ATA and Ultra ATA Controllers, FireWire, USB, and legacy I/O adapters) that bridge the connection between Desktop/Notebook systems and external peripherals. SIIG continues to grow by adding A/V and Digital Signage connectivity solutions to our extensive portfolio.

SIIG products offer comprehensive user manuals, many user-friendly features, and are backed by an extensive manufacturer warranty. High quality control standards are evident by the overall ease of installation and compatibility of our products, as well as one of the lowest defective return rates in the industry. SIIG products can be found in computer retail stores, mail order catalogs, through major distributors, system integrators, and VARs in the Americas and the UK, and through e-commerce sites.

PRODUCTNAME

Cordless Rechargeable LED Folding Light

FCC RULES: TESTED TO COMPLY WITH FCC PART 15, CLASS B OPERATING ENVIRONMENT: FOR HOME OR OFFICE USE

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE PARTY RESPONSIBLE FOR PRODUCT COMPLIANCE SIIG, Inc. 6078 Stewart Avenue Fremont, CA 94538-3152, USA Phone: 510-657-8688

Cordless Rechargeable LED Folding Light is a trademark of SIIG, Inc. SIIG and the SIIG logo are registered trademarks of SIIG, Inc. Microsoft and Windows are registered trademarks of Microsoft Corporation. All other names used in this publication are for identification only and may be trademarks of their respective owners.

August, 2014

Copyright © 2014 by SIIG, Inc. All rights reserved.