



2x1 / 4x1 HDMI 4K HDR KVM USB 3.0 Switch with RC User Manual



04-1367B

P/N: CE-KV0E11-S1
P/N: CE-KV0F11-S1

Features


- Support HDMI 2.0
- Support 4K@60Hz & HDR
- Display EDID bypass
- Support two USB 2.0 ports
for wired mous & keyboard use only
- Support two USB 3.0 5Gbps ports, 5V/900mA
- Support 3.5mm jack for Microphone and Speaker extend
- Switch control by front panel, IR remote or hotkeys
- Support auto-switch mode
- Support Windows and Mac systems
- Plug-n-play, no driver installation

Package Contents

- HDMI 4K HDR KVM USB 3.0 Switch with RC
- Power Adapter 5V/3A
- USB 3.0 Type-A to B cable x 2 (CE-KV0E11-S1)
USB 3.0 Type-A to B cable x 4 (CE-KV0F11-S1)
- IR extender cable
- IR remote control
- User manual

Layout


Front Panel



2x1 & 4x1 port define are the same design,
the manual use 2x1 layout as example.


1. Power Button: Turn on/off the unit
2. Power Indicator:
3. Input Selection Button:
“Select” lights up to indicate input selection
“Link” lights up when the USB-B port is connected.
4. IR EXT: Connect to IR Extender cable
5. IR: For IR signal reception from the remote control
6. Microphone port at console
7. Speaker/Earphone port at console
8. USB 3.0 hub ports at console for peripherals
5Gbps, 5V/900mA

Rear Panel



1. USB keyboard & mouse ports at console
(for wired keyboard & mouse use only)
2. HDMI output: resolution up to 4K@60Hz
3. Microphone port at console
4. Speaker/Earphone port at console
5. PC-x input ports:
Microphone port for PC-x
Speaker/Earphone port for PC-x
USB-B port for PC-x
HDMI input for PC-x
6. Power Jack: DC 5V/3A

Remote Control



P/N: CE-KV0E11-S1 P/N: CE-KV0F11-S1

- **1.2.3.4:** Switch to PC 1 or 2 or 3 or 4
- ◀ : Switch to previous PC
- ▶ : Switch to next PC



Notice:

1. Mouse traversal function: place the mouse on the far right side of the display and continue to slide to the right for 2 seconds, the unit will automatically switches to the next port.
Switching order is : PC1→PC2→PC3→PC4→PC1
2. Hotkey function (It doesn't work on functional keyboard and only the 2 USB-A ports on the back panel can get access to this function.)

Hotkey Command

Hotkey Command	Description
[Scroll Lock] + [Scroll Lock] [→ or ↓]	Switch to the next port
[Scroll Lock] + [Scroll Lock] [← or ↑]	Switch to the previous port
[Scroll Lock] + [Scroll Lock] [N] (N=1 or 2)	Switch to PC N
[Scroll Lock] + [Scroll Lock] [S]	Automatic switching function(Default: 15 sec) Press any key of the keyboard will stop.
[Scroll Lock] + [Scroll Lock] [I] + [Number] [Enter]	Set the automatic switching interval (10~999 seconds)
[Scroll Lock] + [Scroll Lock] [B] + [1/0]	Buzzer on/off (Default: on)
[Scroll Lock] + [Scroll Lock] [F] + [L] + [A] + [S] + [H] [Enter]	All resume hotkey default mode

Application



Dear Valued Customer

**WE REALLY
APPRECIATE
YOUR PURCHASE**

~thank you~

Support

For more info or tech support

<http://www.siig.com/support>

Aug, 2022 Copyright © 2022 by SIIG, Inc. All rights reserved.